


Press and hold button A to enter the menu



**Once in the menu**  
 Press and release button A to navigate up in the menu  
 Press and release button B to navigate down in the menu  
 Press and hold button A to perform the function indicated in the top row of the screen  
 Press and hold button B to perform the function indicated in the bottom row of the screen  
*Note: This presentation is based upon surface mode. While diving the menu can vary slightly to reduce complication.*

**Quick Tips – Using the Dive Computer**

**Cancel Warnings & Alarms**  
 While diving, press and hold Buttons A and B simultaneously to cancel active warnings or alarms

**Custom Function Button (Button B)**  
 Button B can be configured in the SYSTEM → CUSTOM FUNC menu  
 Available options: Best Gas, Stopwatch, Waypoint, or set to Off

**CCR FSP Mode Behavior**  
 When operating in CCR FSP mode, Button B is automatically assigned to toggle between High Setpoint, Low Setpoint, and Bailout

